



Vika X
Assembly Guide

Table of Contents

About this Guide	3
Inside the Box	3
Assembly	4
Uboxing	4
Unfold	4
Handlebars	4
Pedals	5
Adjustments	6
Seat Adjustment	6
Handlebar Adjustment	7
Inflating The Tires	7
Recommended Torque Values	8

About this Guide

Welcome to the assembly guide for your Vika x. We design our products to make it as user-friendly and easy to use as possible, and the assembly guide is no different. We've broken down each step so it's easy to follow whether you're a seasoned pro or an adventure-bound beginner.



WARNING! Before riding your Blix for the first time, double check that all of the hardware on your bike is secured properly to avoid components coming loose which could result in serious injuries.



CAUTION! The following steps are only a general guide to assist in the assembly. We recommend you consult a qualified bike mechanic to assist in the assembly, safety check, service and maintenance of your bike.

Inside the Box

- The Vika X
- Pedals
- Battery
- Charger
- Keys
- Tool Kit
- Manual

Assembly

Step 1: Unboxing

Remove your bike from the box and set it on a smooth, flat surface. Remove all of the packaging material from the bike and carefully cut the zip-ties.

Note: We recommend keeping the box and protective packaging for 30 days after receiving your bike in case any issues arise.

Step 2: Unfold

1. Unfold the frame and firmly engage the latch at the center of the frame.
2. Make sure the security latch is switched downwards to ensure the frame is secure.



Step 3: Handlebars

1. Rotate the handlebar stem upwards and turn the latch upwards to secure the stem.



Step 4: Pedals

1. The pedals are marked with an “L” for left and an “R” for right on the end of the axle. The right pedal should be installed on the side with the chain and gears.
2. Start by hand-threading each pedal onto the bike. Then, tighten the pedals securely using the 15mm crescent wrench.



CAUTION! The left pedal is reverse-threaded and tightens in the opposite direction. Ensure pedals thread correctly before tightening to prevent damage.

Adjustment

Step 5: Seat Adjustment

1. To adjust the seat height, open the quick release seat post clamp and adjust the saddle height to your desired height.

2. Clamp down the quick release to lock in your height.



Saddle Height Min 32" (812 mm)
Saddle Height Max 41.8" (1062 mm)

If the seat post height continues to slip under pressure, open the quick release and tighten the nut on the clamp by hand. Then, close the quick release again to ensure it is securely fastened.



CAUTION! You should be able to comfortably touch the ground with your toes, and should be able to fully extend your legs while pedaling. This is the optimal height for your seat, but choose the height that works best for you.

Step 6: Handlebar Adjustment

The handlebar height can be adjusted using the quick release on the stem. Adjust the stem to the desired angle, and secure tightly to ensure the position doesn't change or slip during use.



This is the only adjustment that should be made to the handlebars when fitting your bike.

Handlebar Height Min 41.7" (1060 mm)
Handlebar Height Max 47.6" (1210 mm)



CAUTION! After adjusting the handlebars, you should be able to sit up straight without slouching, and without the need to hold your arms or wrists in an uncomfortable position. Your comfort is key to having an enjoyable and safe riding experience!

Step 7: Inflating the Tires

Ensure your tires are inflated to the recommended PSI. The PSI is written on the side of the tire for easy reference. A properly inflated tire has lower rolling resistance.



CAUTION! Only inflate the tires to the recommended pressure 40-65 PSI, indicated on the tire sidewall. Within the recommended pressure range listen on the side of the tire.



CAUTION! Ensure your brakes are adjusted properly by checking that your brake levers stop before touching the handlebars. Double-check that the wheel stops spinning when the brakes are depressed.

Recommended Torque Values

Tighten bolts to torque specifications to prevent the bolts from slipping.

Part	Torque (Nm)
Seat Post Clamp	7
Saddle	18-20
Pedals	35
Crank Bolts	40
Handlebar	18-20
Stem	18-20
Rear Wheel	40-45

Recommended Rider Height: 4'10" – 6'2"



WARNING! Do not extend any components including the stem or seat post beyond the minimum insertion markings, which are etched into the seat post and stem. Before using the bike, check that the saddle post quick release bolt is closed and firmly tightened. Secure all hardware properly or it may become loose and result in serious injuries.

Your bike is now fully assembled. Make sure to read the Blix Owner's Manual before riding.

<https://support.blixbike.com/>
(855) 655-BLIX [2549]
blixbike.com

blix