

Packa

Assembly Guide

4. Install the front wheel so that it's fully seated on the front fork dropouts and the disc rotor slides into the brake caliper as shown in video. Tighten the quick release firmly using your hand.
5. Ensure the front wheel is properly installed, centered in the fork, and secured.

Step 7: Install the pedals. They are marked with an "L" for the pedal to install on the left side of the bike and marked "R" for the right side (side with chain and gears).



Tighten the pedals securely by turning the pedals towards the front of the bike with a wrench as seen in the assembly video at support.blixbike.com. Install carefully to not damage the thread.

Step 8: Install the seat. Insert the seat post. Adjust the seat post to the desired height, and firmly tighten the quick release seat post clamp so that it squarely closes against the collar.



Step 9: Install the right and left running boards with the provided bolts as shown in the photo and in the assembly video at support.blixbike.com.



Step 10: Inflate the tires to the recommended pressure of 35-65 PSI, indicated on the tire sidewall.

Step 11: Check brakes and that all bolts are tight before riding.



Assembly video available
at support.blixbike.com

View on phone or desktop!

Do not extend any components including the stem or seat post beyond the minimum insertion markings, which are etched into the seat post and stem. Before using the bike, check that the saddle post quick release bolt is closed and firmly tightened. Secure all hardware properly or it may become loose and result in serious injuries.

Recommended Torque Values

Tighten bolts to torque specifications to prevent the bolts from slipping.

Part	Torque (Nm)
Seat post clamp	7
Saddle	18-20
Pedals	35
Crank bolts	40
Handlebar	18-20
Stem	18-20
Rear wheel	40-45

Notice: The following steps are only a general guide to assist in the assembly of your Blix bike and not a complete guide of all aspects of the assembly. Refer to the assembly video at support.blixbike.com for detailed instructions. We recommend you consult a qualified bike mechanic to assist in the assembly, service and maintenance of your bike.

Step 1: Remove the bike from the box and set it on a smooth, flat surface. Remove all packaging material from the bike and carefully cut the zip-ties attaching the handlebars and wheel to the frame. Make sure the below items are included in the package. Contact Blix if any items are missing.

- The Packa
- Pedals
- Front wheel
- Quick release for front wheel
- Fender for front wheel
- Front light
- Batteries and keys
- Charger
- Tool kit
- Manual

Step 2: Put the bike on the kickstand.

Step 3: Install the handlebars as shown in the assembly video at support.blixbike.com.

1. Make sure the bend of the front fork points forward.
2. Remove the cap at the top of where the handlebars go.
3. Insert the handlebar stem over the top of the fork so it points forward in alignment with the front fork. Open the latch on the stem and screw down the center bolt till tight. (3.3)
4. Rotate the handlebar in the stem to find your desired wrist position, then close the latch to lock the position.
5. Tighten the side bolts on the clamp. (3.5)



Step 4: Install the the front fender and light cables according to assembly video at support.blixbike.com.

1. Route the light cables and tube through the top of the fender, secure the tube through the clamps on the inside, and have them exit through the hole at the front of the fender.
2. Attach the top part of the fender to the attachment on the fork as shown in 4.2.
3. Attach the fender strut to the attachment points on the fork as shown in 4.3.



Step 5: Connect the light cables to the included front light. Cable marked with white color connects to minus (-). Attach the light to the attachment on front of fender with the attached bolt.



Step 6: Install the front wheel as shown in the assembly video at support.blixbike.com.

1. Remove the cap and spring from the quick release skewer as shown in photo. (6.1)
2. Before installing the wheel onto the bike, push the quick release skewer through the axle of the front wheel from the side where the disc is attached. Reattach the spring and cap to the quick release skewer. Make sure the smaller end of the spring faces inwards. (6.2)
3. Remove the plastic fork cover.

