

Blix Sol Rear Rack



Adventure awaits!

Compatibility

This Rear Rack is designed for Blix Sol models from 2019 and later.

Hardware


- 2 x Strut Clamp Mount (A)
- 2 x M6 15mm Socket Bolt (B)
- 2 x M6 12mm Socket Bolt (C)
- 2 x M5 10mm Socket Bolt (D)
- 4 x M6 Washer (E)
- 2 x M5 Washer (F)
- 2 x Strut Clamp Bolt (G)
- 2 x M6 Nut (H)
- 2 x Strut Cap (I)
- 2 x Strut (J)

Tools Required

- 10mm/8mm Combination Wrench (K)
- 5mm Allen Key (L)
- 4mm Allen Key (M)

Instructions




- Assemble the Strut Clamp:** Slide the Strut (J) through the Strut Clamp Bolt (G) and slide the Strut Cap (I) onto the end of the Strut (J). Then, insert the Strut Clamp Bolt (G) into the Strut Clamp Mount (A) and use the M6 Nut (H) to secure it. *(cont.)*



Blix Sol Rear Rack

Instructions (cont.)

1. Tighten the M6 Nut (H) using the 10mm side of the Combination Wrench (K) while using the 5mm Allen Key (L) to stabilize the Strut Clamp Bolt (G). Repeat this process for the second strut.




Blix Sol Rear Rack




Adventure awaits!

Instructions (cont.)



2. **Attach the Strut Clamp to the Rack:** Insert the M6 15mm Socket Bolt (B) through the top of the Rack using one M6 Washer (E), and screw the bolt into the top of the Strut Clamp Mount (A) using the 5mm Allen Key (L), ensuring the strut is on the outside of the rack. Repeat this for the other strut on the other side of the rack.

3. **Attach the Rear Rack to the Frame:** Attach the Rack to the mounting point on the rear dropouts of the frame using one M6 12mm bolt (C) and M6 washer (E) on each side, and screw the bolts in using the 5mm Allen Key (L)



4. **Attach the Strut to the Frame:** Attach the strut to the mounting points on the frame using an M5 10mm bolt (D) and an M5 washer (F) on each side, and screw the bolts in using the 4mm Allen Key (M).