



Vika+ Flex
Assembly Guide

Table of Contents

About this Guide	3
Package Contents	3
Assembly	4
Unpacking your Blix	4
Installing Handlebars	4
Unfolding	5
Installing Pedals	5
Installing Seat	6
Adjustment	6
Adjusting Seat	6
Adjusting Handlebars	7
Inflating Tires	7
Checking Brakes	7

Vika+ Assembly Guide

About this Guide

Welcome to the assembly guide for your Blix Vika+. We craft our bikes with an innovative and user-friendly design, and the assembly guide is no different. We've broken down each step so it's easy to follow whether you're a seasoned pro or an adventure-bound beginner.

A detailed assembly video is also available on mobile and desktop at support.blixbike.com. Navigate to the **Maintenance & Use** tab and scroll down to **Bike Assembly Instructions**. And, of course, if you run into any issues along the way our experienced support team is always here to help.



Tip: We recommend consulting Blix Support to assist in the assembly, service, and maintenance of your bike.

Package Contents

- The Vika+
- Accessories & Small Parts
 - Right & Left Pedals
 - Battery & Charger
 - Keys
- Tool Kit (listed from smallest to largest)
 - 3mm allen wrench
 - 4mm allen wrench
 - 5mm allen wrench
 - 6mm allen wrench
 - 8/10mm crescent wrench
 - 13/15mm crescent wrench



Tip: Before riding your Blix for the first time, double check that all of the hardware on your bike is secured properly to avoid components coming loose which could result in serious injuries.

Assembly

Step 1: Unpacking your Blix

Remove your bike from the box and set it on a smooth, flat surface. Remove all of the packaging material from the bike and carefully cut the zip-ties.



Note: We recommend keeping the box and protective packaging for 30 days after receiving your bike in case any issues arise.

Step 2: Handlebars

1. Rotate the handlebar stem upwards and tighten the knob firmly.



2. Insert the upper part of the handlebar stem into the lower handlebar stem of the bike.
3. Adjust to your desired height and tighten the quick release clamp as firmly as possible to avoid vibration in the handlebar while riding.



Assembly

Step 3: Unfold

1. Unfold the frame and firmly engage the latch at the center of the frame.
2. Rotate the safety latch to ensure the frame is secure.



Step 4: Pedals

1. The pedals are marked with an “L” for left and an “R” for right on the end of the axle. The right pedal should be installed on the side with the chain and gears.
2. Start by hand-threading each pedal onto the bike. Then, tighten the pedals securely using the 15mm crescent wrench.



Note: The left pedal is reverse-threaded and tightens in the opposite direction. Ensure pedals thread correctly before tightening to prevent damage.

Assembly

Step 5: Seat

1. Insert the seat post.
2. Clamp the quick release collar down at your desired height.



Adjustment

Follow the steps below to personalize your Vika+ and to check for safety.

Step 6: Seat Adjustment

To adjust the seat height, open the quick release seat post clamp. Once you've reached your desired height, simply clamp the quick release back down so it squarely closes against the collar. If the seat height continues to slip when pressure is applied, you can tighten the nut on the quick release clamp by hand.



Tip: You should be able to comfortably touch the ground with your toes, and should be able to fully extend your legs while pedaling. This is the optimal height for your seat, but choose the height that works best for you.

Adjustment

Step 7: Handlebar Adjustment



The handlebar height can be adjusted using the quick release on the stem. Adjust the stem to the desired angle, and secure tightly to ensure the position doesn't change or slip during use. This is the only adjustment that should be made to the handlebars when fitting your bike.



Tip: After adjusting the handlebars, you should be able to sit up straight without slouching, and without the need to hold your arms or wrists in an uncomfortable position. Your comfort is key to having an enjoyable riding experience!

Step 8: Tire Inflation

Ensure your tires are inflated to the recommended PSI. The PSI is written on the side of the tire for easy reference. A properly inflated tire has lower rolling resistance.



Note: Inflating your tire at a lower than recommended pressure may cause tires to become flat.

Step 9: Checking Brakes

Ensure your brakes are adjusted properly by checking that your brake levers stop before touching the handlebars. Double-check that the wheel stops spinning when the brakes are depressed.



Note: Our Brake Adjustment guide can be found at support.blixbike.com, but we recommend contacting an experienced bike mechanic for any major adjustments to the brakes.

Recommended Torque Values

Tighten bolts to torque specifications to prevent the bolts from slipping.

Part	Torque (Nm)
Seat Post Clamp	7
Saddle	18-20
Pedals	35
Crank Bolts	40
Handlebar	18-20
Stem	18-20
Rear Wheel	40-45

Your bike is now fully assembled. See the Blix Owner's Manual for tips and instructions on getting the most out of your new Blix.

In Need of Support?

<https://support.blixbike.com/>

(855) 655-BLIX [2549]

blixbike.com

